


PW6LPWS4



PW6LPWS4			
Ref #	Description	Qty	Part #
1	Assembly, Tire Wheel	2	F1065890069013
2	Assembly, Hub	2	2850310P
3	Ubolt, Axle	2	PBN01806
4	Axle	1	MFG000712
5	Clamp, Axle	2	MFG000771
6	Rotor	1	MFG000176R
7	Rotor	1	MFG000176L
8	Line, 1/4 Fuel	1	MFG001611
9	Nipple, 1/8 Close	1	PPF02601
10	Assembly, Tongue Stand	1	MFG001225
11	Axle, Rear	1	G742FA
12	Driveshaft, Rear	1	7744128C2520
13	Bearing	4	123869
14	Shaft	1	MFG000576
15	Key, 3/8 x2	1	MFP02998
16	Key, 3/8 x2	1	MFP02998
17	Flange, Rear Drive	1	MFG001593
18	Shield, PTO	1	MFG001500
19	Clamp, Tongue	6	MFG000770
20	Ubolt, Engine Mount Assembly	6	PBN01805
21	Assembly, Engine Drive Mount	1	MFG001578
22	Insulator, 19"	2	MFG000560
23	Assembly, Fuel Tank Bracket	1	MFG001511
24	Tank, 45 Gallon Fuel	1	MFG001512
25	Assembly, Engine Mounting Plate	1	MFG001575
26	Lister, Engine	1	LPWS4301
27	Bracket, Starter Panel Mounting	1	MFG001571
28	Shield, Flywheel	1	MFG001572
29	Bushing, Lower Sheave	1	120498
30	Bushing, Upper Sheave	1	119056
31	Belt	5	BX78
32	Guard, Belt	1	MFG001563
33	Bracket, Belt Guard	1	MFG001574
34	Sheave, Upper	1	118105
35	Sheave, Lower	1	455704
36	Assembly, Frame	1	MFG001562
37	Box, Battery	1	PMS04741-C